

To Turn on Terminal Please hold down the **RED** key and wait for terminal to boot up. Wait for until the bars in the upper left hand corner turn **blue**.

## How To Use Your FD410DW Wireless Terminal

<b>Credit Card SALE</b> (Swiped or Manually Keyed)	
IDLE PROMPT	Touch <b>Sale</b>
VISA SALE ENTER AMOUNT \$0.00	Key Amount and Press <b>Green Enter</b> Button
CREDIT SALE SWIPE CARD	Swipe card or manually key card number and press <b>Green Enter</b>
EXPIRE DATE MMY	Key expiration date and press <b>Green Enter</b> button
VISA SALE IS CARD PRESENT	Will ask if card is present and press <b>YES</b> on the screen
DIALING.....	Terminal communicates with the host for approval
VISA SALE ZIP CODE	Enter in zip code of cardholder and press green enter button
PRINT CUST RECEIPT	Touch <b>Yes</b> to print customer receipt
APPROVED OK 0000-00 AVS = XXX	Press Clear to return to idle prompt

<b>Debit Card SALE</b> Use this function to authorize and capture transactions for settlement.	
IDLE PROMPT	Touch <b>Sale</b>
VISA SALE ENTER AMOUNT \$0.00	Key Amount and Press <b>Green Enter</b> Button
DEBIT SALE SWIPE CARD	Swipe card on terminal or pinpad. Terminal will know if card is a Debit card.
VISA SALE PLEASE ENTER PIN	Instruct customer to enter PIN and press <b>Green enter</b> button. <b>Do not ask customer for the PIN.</b>
DIALING.....	Terminal communicates with the host for approval
PRINT CUST RECEIPT? YES NO	Touch <b>Yes</b> to print customer receipt
DEBIT SALE APPROVED 000000	Press Clear to return to idle prompt

<b>VOID for Credit Card Sale</b> Use this function to delete a transaction that is in the current batch.	
IDLE PROMPT	Touch <b>Other</b>
OTHER OPTIONS	Touch <b>VOID</b>
ENTER SEQUENCE #	Key sequence number and press <b>Green Enter</b> button
VOID TRANSACTION	Touch <b>Void</b>
VOID TRANS? YES NO	Touch <b>Yes</b>
VOID COMPLETE VS VOID SALE 0000	Press <b>Clear</b> yellow button to return to idle prompt

**SALE WITH SNAP/EBT CARDS** Use this function to authorize and capture transactions for settlement.

IDLE PROMPT	Touch <b>Other</b>
OTHER OPTIONS	Touch <b>More</b>
OTHER OPTIONS	Touch <b>EBT</b>
EBT SALE	Touch Sale
EBT SALE	<b>Food Stamps or Cash benefits.</b> Select card type.
EBT SALE SWIPE CARD	Swipe card or manually key card number and press <b>Green enter</b> button
EBT SALE ENTER AMOUNT \$0.00	<b>Enter</b> amount and press <b>Green Enter</b> button.
DIALING.....	Terminal communicates with the host for approval
PRINT CUST RECEIPT YES NO	Touch <b>Yes</b> to print customer receipt

**HOW TO PROCESS MANUAL SNAP/EBT VOUCHER:**  
See Separate Instruction Guide

**VOID For EBT Transaction** Use this function to delete a transaction that is in the current batch.

IDLE PROMPT	Touch <b>Other</b>
OTHER OPTIONS	Touch <b>More</b>
OTHER OPTIONS	Touch <b>EBT</b>
EBT SCREEN	Touch <b>Void</b>
EBT VOID SCREEN	Enter transaction sequence # from receipt. Then press <b>green Enter</b> button.
VOID TRANS?	Touch <b>VOID</b>
VOID COMPLETE	Performing EBT reversal
Completed	

**FOR 24 Hour  
TECHNICAL SUPPORT  
CALL: 1-877-274-7915**

**Closing Batch** You must close batch at the end of each processing day in order to get your money in your bank.

IDLE PROMPT	Touch <b>Other</b>
OTHER OPTIONS	Touch <b>Close Batch</b> (upper right corner)
CLOSE BATCH	Press <b>green Enter</b> button.
CLOSING BATCH	Transmitting
PRINT RECEIPT	Once done will print receipt with batch total.

**Paper or Supplies or to add more terminals Call:  
MerchantSource®  
1-800-313-5198**